User manual

Personal ioniser

Attention! Do not touch the needles when unit turned on!

Function:

By the combination of three of the world's most recognized technologies of purification, **AIRBUTLER** Andrew is able to guarantee a maximum of purification: dust purification, removal of bacteria and elimination of nasty odours. All that can be achieved by a very powerful generator of ions. It produces negatively charged ions, which are able to destroy virus and mites. The power consumption is only 0.8 W.

Well-being effect:

This is your personal ioniser and air purifier that you can have on everywhere. It uses a special ionising technology based on coroner discharge in order to let you breathe fresh air, no matter where you are. This lightweight ioniser is also able to humidify the air around your nose and mouth.

Bond of dust:

After a few days of use, you will find a considerably deposit of air pollutants on the metal dust collectors inside the device.

Low-noise construction:

AIRBUTLER Andrew works without fan and is silently.

ANDREW

Applicable areas:

AIRBUTLER Andrew is to have on around your neck. The appliance eliminates dust, bacteria directly in front of your mouth and nose. The air you breathe Attention! Personal ioniser is clean, fresh and full of negative ions. You can humidify the air by dropping some water into the cavities suited for this purpose.

Start-up:

The device can work with different energy sources:

- Batteries: open the battery compartment and put in 4 AAA batteries. Take care of the right polarity. Close the cover and check if it is well locked.
- Adapter: use the provided adapter of 12 V to connect the device.

Switch on the device at the front. The green lamp indicates that the appliance is working. The auto-timer stops the appliance after 30 minutes, if you want to stop it earlier, just press the on-button again. The blinking red lamp indicates that the batteries are low and that should be replaced. The ring around the ioniser outlets is made of water absorbing polymer, which can be charged with a certain quantity of water to humidify the air.

Setting:

The ribbon should be adjusted to the right length, about 20 cm from your nose and mouth.

Humidification of the cavities:

Only use clean water. Use the delivered pipette for injecting carefully the water into the rings around the outlets. Each ring can absorb about 10 drops of water (a third of a pipette volume). Never fill in too much water to avoid damage or short-circuit.

Cleaning / Maintenance:

After 1 month of use the front cover should be carefully removed and cleaned. Unlock the buttons at the bottom of the device and pull off carefully the front side. Use cotton buds for cleaning the collector rings and the electrodes of the unit. Replace the cover properly and restart the device, when all parts are dry again.

IMPORTANT:

- Do not insert any metallic objects into the unit to prevent electrical shocks and

damage. Do not place the unit close to inflammable and explosive objects.

- Do not use alcohol or benzene for cleaning the casing to avoid any damage on the surface.
- Do not use **AIRBUTLER** Andrew close to areas of magnetic interferences.
- Do not hit or drop **AIRBUTLER** Andrew.

Further information:

This ioniser purifies air; it is not a substitution of regular airing of rooms. Do not modify the appliance in any way. Neither the manufacturer nor the trader can accept any responsibility of any kind damage thus resulting.

Accessories:

1 power adapter 230 V
1 PVC ribbon
1 pipette

Technical Data:

Type	**AIRBUTLER** Andrew
Voltage	230 V / 4 x AAA Batteries
Power consumption	0,8 W
Negative ions	> 2 x 10^5
Active oxygen	< 0,02 ppm
Dimension	110 x 81 x 27 mm
Weight	110 g
Applicable area	everywhere

AIRBUTLER reserves the right of any technical modifications of the appliance.

Warranty for ANDREW

AIRBUTLER® Medcare

1. All **AIRBUTLER** products are subjected to stringent testing before they leave the factory. Guarantee of function for two years from date of purchase.

2. Damage and malfunctions within the warranty period are only dealt with on presentation of the completed warranty certificate. Please return the appliance to the trader so that the cause of malfunction can be identified. If the damage or malfunction is due to a production fault then the appliance will be repaired immediately or replaced with a new appliance. Damage which is not due to a production fault cannot be taken into account.

3. The warranty does not include any damage due to incorrect handling, faulty reassembly, manual conversion in or on the appliance, omission of cleaning, exterior damage to the appliance or obvious damage to the interior of the casing (such as e.g. lightning, artificial cause or natural events).

4. The date on the warranty certificate and submission of the bill are imperative for any warranty claims.

✂

Name: _____

Address: _____

Purchase date: _____

Phone: _____

Stamp of trader: _____

We are at your service for questions or application problems: **office@airbutler.com**

CE DER GRÜNE PUNKT RoHS 2002/95/EC ISO 9001